
CAE PERFORMANCE PRODUCTS PTY/LTD

Pyrenees Hwy Chewton, VIC. 3450
Telephone : (03) 5472 1442 - Fax (03) 5472 4111

CH47 Fitting Instructions ***Fitting time 3hrs***

Remove battery terminals and spark plug leads.
Place vehicle on hoist.

Drivers Side

Nearly all bolts can be accessed from above the engine bay. The remaining bolts can be accessed from underneath the vehicle.

Remove manifold by sliding it forward towards the radiator, lift the nose of it up towards the alternator, then drop the rear out in front of the sway bar.

Fit headers from under car, push headers over bell housing and starter. With a bit of a twist they should sit in place on head.

Clean face of head surface then fit with new extractor bolts.

Tighten with 7/16" or 11mm ring spanner.

Note: We recommend using Permatex Ultra Blue RTV silicone gasket maker. This is Cat Converter and Oxy sensor safe.

Passengers Side

All bolts accessed from under car.

Remove manifold by sliding back and down.

Clean face of head.

Silastic gasket and fit headers from under car.

Fit new extractor bolts and tighten.

Double check all bolts and re-fit spark plug leads and battery terminals.